



PLUSSOUND



MICRO ADAPTERS
QUICK START GUIDE

SPECIFICATIONS

Contact Material: Cryogenically Treated Gold Plated
Tellurium Copper

Insulation Material: Black PEEK

Logo: Laser Engraved

Dimensions: Approx. 5mm x 10mm

INSTRUCTIONS

Carefully insert adapters into earphones before inserting into cable.

Make sure PS logo is facing forward for correct polarity.

To remove adapters, carefully pull out from earphones first,
then from the cable, and store them in a safe place.



SAFETY PRECAUTIONS

Do not place very heavy objects over the adapters.

Avoid places with moisture, dust, or smoke.

Avoid exposing the adapters to direct sunlight or extreme temperatures.

Keep clean and store in cool area after each use.

Never use chemical or cleaning products on the adapters or it will alter surface.

Avoid dropping or exposing adapters to strong vibrations.

If the adapters gets wet (rain, water, chemical, etc.) allow it to dry.
If it does not work, contact PLUSSOUND for further instructions.

If you experience ringing in your ears, lower the volume or stop listening until it goes away.

Do not listen to music at excessive volume. Protect your ears.

Use in safe environments to avoid accidents.

Be aware of your surroundings especially outdoors while using your setup.

Do not modify or tamper the adapters. This will void warranty and may result in unnecessary damaging of components.

Keep this product out of reach of small children.